



UART & SPI

Lecture 5



UART & SPI

used by RP2350

- Direct Memory Access
- Buses
 - Universal Asynchronous Receiver and Transmitter
 - Serial Peripheral Interface
- Analog and Digital Sensors



DMA

Direct Memory Access



Bibliography

for this section

Raspberry Pi Ltd, RP2350 Datasheet

- Chapter 12 - *Peripherals*
 - Chapter 16.6 - *DMA*




DMA

- offloads the MCU from doing **memory to memory** operations
- due to MMIO, usually implies **transfers from and to peripherals**
- raises an interrupt when a transfer is done

⚠ DMA does not know about the data stored in cache.

- for chips that use cache
 - the DMA buffer's memory region has to be set manually to *nocache* (if MCU knows)
 - or, the cache has to be flushed before and, possibly after, a DMA transfer





UART

Universal Asynchronous Receiver and Transmitter



Bibliography

for this section

1. **Raspberry Pi Ltd**, *RP2350 Datasheet*

- Chapter 12 - *Peripherals*
 - Chapter 12.1 - *UART*

2. **Paul Denisowski**, *Understanding Serial Protocols*


3. **Paul Denisowski**, *Understanding UART*




UART

aka serial port

- connects **two devices**
- uses two **independent** wires
 - *TX* - transmission wire
 - *RX* - reception wire
- cross-connected



Transmission example





UART Device

properties

bits

the number of bits in the payload, between 5 and 9

parity

add or not the parity bit


stop

the number of stop bits to add, 1 or 2

baud

rate

number of elements sent per s, most used **9600** or **115200**





$$baud_{rate} = \frac{f_{clock}}{divider \times (1 + payload_{bits} + parity_{bits} + stop_{bits})}$$



UART Device

types



- **TTL - Transistor Transistor Logic**
connects devices at 0 - 3.3V or 0 - 5V, used for short cables and jumper wires
- **RS232** - used for external connections and longer cables, uses -12V to 12V.
- **RS485** - industrial, uses differential voltage





Receiver

RX part of the serial port





- *Shift Register to read serially every bit*
- Triggers an interrupt
 - when data was received
 - (*optional*) when FIFO is half full
 - (*optional*) when FIFO is full
- FIFO is optional
 - may have a capacity of 1



Transmitter

TX part of the serial port



- *Shift Register to output serially every bit*
- Triggers an interrupt
 - when data was sent
 - (*optional*) when FIFO is half empty
 - (*optional*) when FIFO is empty
- FIFO is optional
 - may have a capacity of 1



Transmission Examples

Setup	Payload	Parity	Stop
8N1	8 bits	no	1 bit
8P2	8 bits	yes	2 bits
9P1	9 bits	yes	1 bit

Diagram illustrating the timing and structure of three transmission formats:

- 8N1:** Shows 8 data bits (b7 to b0) and 1 stop bit. The payload is labeled "payload".
- 8P2:** Shows 8 data bits (b7 to b0), 1 parity bit (p), and 2 stop bits. The payload is labeled "payload".
- 9P1:** Shows 9 data bits (b8 to b0), 1 parity bit (p), and 1 stop bit. The payload is labeled "payload".

The diagram includes a "Clock" signal at the top and "electrical signal" waveforms for each format. The "start" and "stop" fields are indicated by hatched regions.

The diagram illustrates the timing and structure of three transmission formats:

- 8N1:** Shows 8 data bits (b7 to b0) and 1 stop bit. The payload is labeled "payload".
- 8P2:** Shows 8 data bits (b7 to b0), 1 parity bit (p), and 2 stop bits. The payload is labeled "payload".
- 9P1:** Shows 9 data bits (b8 to b0), 1 parity bit (p), and 1 stop bit. The payload is labeled "payload".


The diagram includes a "Clock" signal at the top and "electrical signal" waveforms for each format. The "start" and "stop" fields are indicated by hatched regions.




Successive Transmission

using the 8N1 data format

Back to back




With delay





Facts


Transmission	<i>duplex</i>	data can be sent in both directions at the same time
Clock	<i>independent</i>	there is no clock sent between the two devices, the receiver has to synchronize its clock with the transmitter to be able to correctly read the received data
Wires	<i>RX / TX</i>	one receive write, one transmit wire, independent of each other
Devices	2	a receiver and a transmitter
Speed	<i>115 KB/s</i>	usually a maximum baud rate of 115200 is used





Usage

- print debug information
- device console
- RP2350 has two USART devices





Embassy API

for RP2350, synchronous

```
pub struct Config {  
    pub baudrate: u32,  
    pub data_bits: DataBits,  
    pub stop_bits: StopBits,  
    pub parity: Parity,  
    pub invert_tx: bool,  
    pub invert_rx: bool,  
    pub invert_rts: bool,  
    pub invert_cts: bool,  
}
```

```
pub enum DataBits {  
    DataBits5,  
    DataBits6,  
    DataBits7,  
    DataBits8,  
}
```

```
pub enum StopBits {  
    STOP1,  
    STOP2,  
}
```

```
pub enum Parity {  
    ParityNone,  
    ParityEven,  
    ParityOdd,  
}
```

```
1  use embassy_rp::uart::Config as UartConfig;  
2  let config = UartConfig::default();  
3  
4  // use UART0, Pins 0 and 1  
5  let mut uart = uart::Uart::new_blocking(p.UART0, p.PIN_0, p.PIN_1, config);  
6  // write  
7  uart.blocking_write("Hello World!\r\n".as_bytes());  
8  
9  // read 5 bytes  
10 let mut buf = [0; 5];  
11 uart.blocking_read(&mut buf);
```



Embassy API

for RP2350, asynchronous

```
1  use embassy_rp::uart::Config as UartConfig;
2
3  bind_interrupts!(struct Irqs {
4      UART0_IRQ => BufferedInterruptHandler<UART0>;
5  });
6
7  let config = UartConfig::default();
8
9  // use UART0, Pins 0 and 1
10 let mut uart = uart::Uart::new(p.UART0, p.PIN_0, p.PIN_1, Irqs, p.DMA_CH0, p.DMA_CH1, config);
11
12 // write
13 uart.write("Hello World!\r\n".as_bytes()).await;
14
15 // read 5 bytes
16 let mut buf = [0; 5];
17 uart.read(&mut buf).await;
```



SPI

Serial Peripheral Interface



Bibliography

for this section

1. Raspberry Pi Ltd, *RP2350 Datasheet*

- Chapter 12 - *Peripherals*
 - Chapter 12.3 - *SPI*


2. Paul Denisowski, *Understanding SPI*



SPI

a.k.a *spy*

- Used for communication between integrated circuits
- Sensors usually expose an *SPI* and an *I2C* interface
- Two device types:
 - *main* (master) - controls the communication (usually MCU)
 - *sub* (slave) - receive and transmit data when the *main* requests (usually the sensor)







Wires

3 + n

- **MOSI - Main Out Sub In** - carries data from the **main** to the **subs**
- **MISO - Main In Sub Out** - carries data from the active **sub** to the **main**
- **CLK** - Clock signal generated by the **main**, **subs** sample and write data to the bus only on the clock edge
- **CS*** - **Chip Select** - not actually part of SPI, one wire / sub, activates **one sub at a time**
 - inactive subs have to disconnect from the *MOSI* and *MISO* lines







Transmission Example

1. **main** activates the sub device
 - sets the `CS` signal to `LOW`
2. at the same time
 - **main** puts the first bit on the `MOSI` line
 - **sub** puts the first bit on the `MISO` line
3. **main** starts the clock
4. at the *rising edge*
 - **main** reads the data from the `MISO` line
 - **sub** reads the data from the `MOSI` line
5. on the *falling edge*
 - **main** puts the next bit on the `MOSI` line
 - **sub** puts the next bit on the `MISO` line
6. repeat 4 and 5 until **main** decides to stop the clock

SPI Signals



SPI Network






SPI Modes

when data is read and written

Mode	CPOL	CPHA
0	0	0
1	0	1
2	1	0
3	1	1



defines when the data bit is read

- 0: *rising edge*
- 1: *falling edge*


defines when the data is written to the line

- 0: when `CS` activates or *clock edge*
- 1: on *clock edge* (depends on `CPOL`)



Transmission Example

one main, two subs



1. **main** activates the CS pin of **sub 1**
2. **main** writes the first bit on MOSI, **sub 1** writes the first bit on MISO
3. **main** starts the clock
4. **main** and **sub 1** send the rest of the bits
5. **main** stops the clock
6. **main** deactivates the CS pin of **sub 1**

7. **main** activates the CS pin of **sub 2**
8. **main** writes the first bit on MOSI, **sub 2** writes the first bit on MISO
9. **main** starts the clock
10. **main** and **sub 2** send the rest of the bits
11. **main** stops the clock
12. **main** deactivates the CS pin of **sub 2**




Daisy Chaining


using several SPI devices together

1. **main** activates all the **subs**
2. on the clock edge
 - **main** sends data to **sub 1**
 - **sub 1** sends data to **sub 2**
 - ...
 - **sub n-1** sends data to **sub n**
 - **sub n** sends data to **main**

activate all the **sub** devices



1. usually **subs** send the previous data bit received from **main** to the **next sub** ↵





Facts

Transmission	<i>duplex</i>	data must be sent in both directions at the same time
Clock	<i>synchronized</i>	the main and sub use the same clock, there is no need for clock synchronization
Wires	<i>MISO / MOSI / CLK / CS</i>	different read and write wires, a clock wire and an <i>optional</i> chip select wire for every sub
Devices	<i>1 main several subs</i>	a receiver and a transmitter
Speed	<i>no limit</i>	does not have any limit, it is limited by the main clock and the electronics wirings



Usage

- EEPROMs / Flash (usually in *QSPI* mode)
 - Raspberry Pi Pico has its 2MB Flash connected using *QSPI*
- sensors
- small displays
- RP2350 has two SPI devices



Embassy API

for RP2040, synchronous

```
pub struct Config {  
    pub frequency: u32,  
    pub phase: Phase,  
    pub polarity: Polarity,  
}
```

```
pub enum Phase {  
    CaptureOnFirstTransition,  
    CaptureOnSecondTransition,  
}
```

```
pub enum Polarity {  
    IdleLow,  
    IdleHigh,  
}
```

```
1  use embassy_rp::spi::Config as SpiConfig;  
2  let mut config = SpiConfig::default();  
3  config.frequency = 2_000_000;  
4  
5  let miso = p.PIN_12;  
6  let mosi = p.PIN_11;  
7  let clk = p.PIN_10;  
8  let mut spi = Spi::new_blocking(p.SPI1, clk, mosi, miso, config);  
9  
10 // Configure CS  
11 let mut cs = Output::new(p.PIN_X, Level::Low);  
12  
13 cs.set_low();  
14 let mut buf = [0x90, 0x00, 0x00, 0xd0, 0x00, 0x00];  
15 spi.blocking_transfer_in_place(&mut buf);  
16 cs.set_high();
```



Embassy API

for RP2040, asynchronous

```
1  use embassy_rp::spi::Config as SpiConfig;
2  let mut config = SpiConfig::default();
3  config.frequency = 2_000_000;
4
5  let miso = p.PIN_12;
6  let mosi = p.PIN_11;
7  let clk = p.PIN_10;
8  let mut spi = Spi::new(p.SPI1, clk, mosi, miso, p.DMA_CH0, p.DMA_CH1, config);
9
10 // Configure CS
11 let mut cs = Output::new(p.PIN_X, Level::Low);
12
13 cs.set_low();
14 let tx_buf = [1_u8, 2, 3, 4, 5, 6];
15 let mut rx_buf = [0_u8; 6];
16 spi.transfer(&mut rx_buf, &tx_buf).await;
17 cs.set_high();
```



Sensors

Analog and Digital Sensors



Bibliography

for this section

BOSCH, BMP280 Digital Pressure Sensor

- Chapter 3 - *Functional Description*
- Chapter 4 - *Global memory map and register description*
- Chapter 5 - *Digital Interfaces*
 - Subchapter 5.3 - *SPI Interface*




Sensors

analog and digital


Analog

- only the transducer (the analog sensor)
- outputs (usually) voltage
- requires:
 - an ADC to be read
 - cleaning up the noise



Digital


- consists of:
 - a transducer (the analog sensor)
 - an ADC
 - an MCU for cleaning up the noise
- outputs data using a digital bus





BMP280 Digital Pressure Sensor

schematics



Datasheet



BMP280 Digital Pressure Sensor

registers map

Register Name	Address	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	Reset state
temp_xlsb	0xFC		temp_xlsb<7:4>			0	0	0	0	0x00
temp_lsb	0xFB				temp_lsb<7:0>					0x00
temp_msb	0xFA				temp_msb<7:0>					0x80
press_xlsb	0xF9		press_xlsb<7:4>			0	0	0	0	0x00
press_lsb	0xF8				press_lsb<7:0>					0x00
press_msb	0xF7				press_msb<7:0>					0x80
config	0xF5	t_sb[2:0]			filter[2:0]			spi3w_en[0]		0x00
ctrl_meas	0xF4	osrs_t[2:0]			osrs_p[2:0]		mode[1:0]			0x00
status	0xF3				measuring[0]			im_update[0]		0x00
reset	0xE0			reset[7:0]						0x00
id	0xD0			chip_id[7:0]						0x58
calib25...calib00	0xA1...0x88			calibration data						individual


Registers:	Reserved registers	Calibration data	Control registers	Data registers	Status registers	Revision	Reset
Type:	do not write	read only	read / write	read only	read only	read only	write only

Datasheet



Reading from a digital sensor

using synchronous/asynchronous SPI to read the `press_lsb` register of BMP280




```
1 const REG_ADDR: u8 = 0xf8;
2
3 // enable the sensor
4 cs.set_low();
5
6 // buffer[2]: the address and "empty" value
7 let mut buf = [(1 << 7) | reg, 0x00];
8 spi.blocking_transfer_in_place(&mut buf);
9
10 // disable the sensor
11 cs.set_high();
12
13 // use the value
14 let pressure_lsb = buf[1];
```

```
1 const REG_ADDR: u8 = 0xf8;
2
3 // enable the sensor
4 cs.set_low();
5
6 // two buffers[2], writing and reading
7 let tx_buf = [(1 << 7) | REG_ADDR, 0x00];
8 let mut rx_buf = [0u8; 2];
9 spi.transfer(&mut rx_buf, &tx_buf).await;
10
11 // disable the sensor
12 cs.set_high();
13
```



Writing to a digital sensor

using synchronous/asynchronous SPI to set up the `ctrl_meas` register of the BMP280 sensor



```
1 const REG_ADDR: u8 = 0xf4;
2
3 // see subchapters 3.3.2, 3.3.1 and 3.6
4 let value = 0b100_010_11;
5
6 // enable the sensor
7 cs.set_low();
8
9 // buffer[2]: the address and "empty" value
10 let mut buf = [!(1 << 7) & reg, value];
11 spi.blocking_transfer_in_place(&mut buf);
12
13 // disable the sensor
14 cs.set_high();
```

```
1 const REG_ADDR: u8 = 0xf4;
2
3 // see subchapters 3.3.2, 3.3.1 and 3.6
4 let value = 0b100_010_11;
5
6 // enable the sensor
7 cs.set_low();
8
9 // two buffers[2], writing and reading (ignored)
10 let tx_buf = [!(1 << 7) & REG_ADDR, value];
11 let mut rx_buf = [0u8; 2];
12 spi.transfer(&mut rx_buf, &tx_buf).await;
13
```



Conclusion

we talked about

- Direct Memory Access
- Buses
 - Universal Asynchronous Receiver and Transmitter
 - Serial Peripheral Interface
- Analog and Digital Sensors